

| ltem | 16mm | Description | Potential Problem | Measure | Recommended Inspection, Potential Replacement* | Latest Replacement after |
|-------|-------------------|--|---------------------------|-----------|---|--------------------------------|
| Syste | m Joint | | | | | |
| 1 | SB9669-L0760 | bearing nut | wear | replacing | every 6 months | 36 months |
| 3 | SF0393-02 | feather key with pin | breakage | replacing | every 6 months | 36 months |
| 4 | GS2210-040 | | wear | replacing | every 6 months | 18 months |
| 4 | GS2210-045 | sliding washer, Ø = 22mm | | | | |
| 4 | GS2210-050 | | | | | |
| 4 | GS2210-055 | | | | | |
| 4 | GS2210-060 | | | | | |
| 5 | SF0863-L/AL | cover plate, left lateral or right medial** | wear | replacing | every 6 months | 36 months |
| 5 | SF0863-R/AL | cover plate, left medial or right lateral** | | | | |
| 6a | VE3771-09/15 | O-ring for securing the alignment screw** | wear | replacing | every 6 months | 18 months |
| 6c | FE1027-01 | pressure spring** | wear | replacing | every 6 months | 18 months |
| 6d | GS1108-500 | sliding bushing** | wear | replacing | every 6 months | 18 months |
| 6e | VE3771-012/26 | O-ring damper** | wear | replacing | every 6 months | 18 months |
| 6f | SH0493-01 | plunger** | wear | replacing | every 6 months | 36 months |
| 8 | FE2945-01 | pressure spring, golden** | wear | replacing | every 6 months | 18 months |
| 9 | SF0843-10 | pin** | wear | replacing | every 6 months | 36 months |
| 11 | SC1405-L12 | countersunk flat head screw with hexalobular socket** | wear | replacing | every 6 months | 36 months |
| 12 | SC1405-L12 | countersunk flat head screw with hexalobular socket (axle screw)** | | | | |
| 5-12 | SF8973-L/AL | functional unit plug + go modularity, left lateral or right medial*** | loss of function, wear | replacing | every 6 months | 36 months |
| 5-12 | SF8973-R/AL | functional unit plug + go modularity, left medial or right lateral*** | | | | |
| Syste | m Stirrups, Syste | m Anchors and System Side Bars | | | | |
| 13 | BR1110-L030 | sliding bushing | wear | replacing | every 6 months | 18 months |
| 14 | see catalogue | system stirrup | wear or breakage | replacing | every 6 months | 48 months |
| 15 | see catalogue | system anchor and system side bar | wear or breakage | replacing | every 6 months | if required |

* depending on the assessment of the distributor of the custom-made product regarding the patient's usage behaviour

** is part of the functional unit

*** included system components can be exchanged separately