

# Joint Overview System Knee Joints

Use our  
Orthosis Configurator



www.orthosis-configurator.com



	NEURO CLASSIC ZERO	NEURO VARIO ZERO	NEURO CLASSIC	NEURO VARIO	NEURO ACTIVE	NEURO CLASSIC H <sub>2</sub> O	NEURO MATIC	NEURO TRONIC	NEURO LOCK	NEURO LOCK MAX	NEURO FLEX MAX Lock Function	NEURO FLEX MAX Step Lock Function	NEURO LOCK H <sub>2</sub> O
CONTROL MECHANISM	free moving without posterior offset	✓	✓	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗
	free moving with posterior offset	✗	✗	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	automatic stance phase control (mechanical)	✗	✗	✗	✗	✗	✓	✗	✗	✗	✗	✗	✗
	automatic stance phase control (electromechanical)	✗	✗	✗	✗	✗	✗	✓	✗	✗	✗	✗	✗
EXTENSION STOP	permanently locked	✗	✗	✗	✗	✗	✓	✓	✓	✓	✓	✓	✓
	damped	✓	✓	✓	✓	✗	✓	✓	✗	✗	✗	✗	✗
	adaptable by exchanging the extension stop	✗	✓	✗	✓	✓	✗	✗	✓	✓	✓	✓	✗
	adaptable by exchanging the joint's upper part	✓	✗	✓	✗	✗	✓	✓	✗	✗	✗	✗	✗
FLEXION STOP	adaptable by inserting a flexion stop	✗	✗	✗	✗	✓	✗	✗	✗	✗	✓	✓	✗
	adaptable by exchanging the extension stop and adjusting the joint's lower part by filing	✗	✗	✗	✗	✗	✗	✗	✓	✓	✗	✗	✗
LOCK FUNCTION	adaptable by exchanging the extension stop and adjusting the flexion stop disc by filing	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗	✗
	adaptable by exchanging the extension stop and, if necessary, exchanging the step lock stop disc	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗
	step lock function	✗	✗	✗	✗	✗	✗	✗	✗	✗	✗	✓	✗
	water-resistant	✗	✗	✗	✗	✓	✗	✗	✗	✗	✗	✗	✓